BOOMPODS™

power . anywhere . everywhere

User Manual

BOOMPODS™ designed in the UK by DT-Design Ltd. All rights reserved ©2013.
This product uses BOOMPODS™ technology and is covered by international patents, ***POWER****POD*- IP: 201230133252.3

CE FC RoHS 2002/95/EC

POWER*POD 2000mAh phone recharger*

Introduction:
Before using your ***POWER****POD* charger for the first time, please take a few moments to read through the user manual.

POWER*POD*



1 - 30-pin adaptor 2 - Micro USB connector 3 - Flip-out power connector 4 - LED indicator 5 - On/off switch 6- Micro USB charging point



Use:
To charge your phone, simply pull out the integrated flip-out power connector from underneath and attach to your phone with correct connector (Micro USB or 30-pin adaptor supplied). Switch on ***POWER****POD* and leave connected until your phone is fully charged. The 4 LED lights will diminish on the back of the ***POWER****POD* as your phone becomes charged. Once all the lights have gone out, your ***POWER****POD* will need to be recharged. If your ***POWER****POD* is left switched on and not connected to a device it will automatically power down and switch off. To re-activate, you will need to switch off and on again.

Charging:
The LED lights on your ***POWER****POD* charger will flash blue in 4 stages, it is fully charged once all 4 LED lights are solid blue.

LED	•	••	•••	••••
Power level	25%	50%	75%	100%

Your ***POWER****POD* contains a LiPo battery. Please use the provided Micro USB cable to charge the battery through a PC or USB mains charger. Normally it will take 3-4 hours to fully charge the battery.

Package contents:
1 x ***POWER****POD* portable phone recharger
1 x Micro USB cable
1 x flip-out Micro USB connector
1 x 30-pin adaptor
1 x user manual

Technical details:
•Battery capacity: 2000mAh
•Charge time: 3-4 hours

General guidelines:
Keep away from high temperature or prolonged exposure to direct sunlight.
Avoid contact with liquids.
Do not disassemble.
Do not twist or force cable upward (see diagram)
Do not drop the product.
Keep out of reach of children.

Warranty :
Your **BOOM**PODS™ product is warranty against any defects in material or workmanship for one year from the date of original purchase providing it has not been disassembled and it has not suffered accidental damage such as a knock or immersion in water, etc.

The device must be used in accordance with the user manual. The guarantee is subject to presentation of the original invoice or receipt from the retailer and does not apply to normal wear and tear or to any device that has been misused or tampered with. It should be returned to the local service centre, the service centre will not bear any shipping cost of the returned item.



DO NOT TWIST CABLE DO NOT FORCE UP
this could cause irreparable damage.

Please check www.boompods.com for your local service centre.

BOOMPODS™
www.boompods.com